


PCR808 Elastyczne zamknięcie z szyfrem

Szybko i łatwo zabezpiecza drzwi szafek. Elastyczne zamknięcie z szyfrem, dzięki sprytnemu systemowi szyfrowemu sprawi, że twoje ciekawskie dziecko nie będzie mogło dostać się do szaf. Odpowiednie do stosowania na gałkach drzwiowych i uchwytach drzwiowych w kształcie litery D.




Resetowanie szyfru:

1. Naciskając przycisk wyzwalacza, wciśnij końcówkę linki do punktu zakotwiczenia (A);
2. Przesuń rzędy cyfr szyfrowania, by ustawić własny szyfr (B);
3. Przytrzymuj przycisk wyzwalacza w pozycji wciśniętej, wyciągnij końcówkę linki - teraz Twój osobisty szyfr jest już ustawiony.



Zamykanie:




Otwieranie:

1. Przesuń cyfry (5) ustawiając wybrany szyfr;
 2. Naciśnij (7) zwolnienie linki.
- UWAGA:** W mechanizmie linki znajduje się sprężynka. Dla bezpieczeństwa, gdy końcówka linki wraca do punktu zakotwiczenia, przytrzymaj ją. Zachowaj etykietę ze względu na ważne informacje. Opakowanie nie jest integralną częścią produktu i należy je usunąć wraz z wszystkimi jego elementami. Opakowanie nie służy do zabawy. W przypadku reklamacji zaleca się zachowanie nazwy dystrybutora, symbolu towaru oraz opakowania.

Cable Lock


F808

Dream Baby® Cable Lock will help prevent curious toddlers from opening cabinets with its clever combination locking system. Suitable for use with mushroom shaped knobs or D-shaped handles.




To reset the combination:

1. While pressing Trigger Button, press down the Cable Tip into Anchor Point (A).
2. Turn the Combination Dials to your own personal numbers (B).
3. While holding down Trigger Button, pull out Cable Tip - your personal code is now set.



To Lock:



To Unlock:

1. Turn (5) Dials to combination.
2. Press (7) Cable Release.

Caution: The Cable mechanism is spring loaded. For safety, hold the Cable Tip as it retracts back into the Anchor Point.

There is no substitute for proper adult supervision. This product is only a deterrent. Discontinue use when child is able to open it.

Note: All dangerous and toxic substances, sharp edged or pointed objects should always be kept 'high up' or in an area totally inaccessible to children.